

Power-Save Quick Sizing Guidance Chart

PHASE

1. Single or 3 phase?	Single	1200
	3 Phase	3200/3400

LOAD

2. Distribution load?	200 Amp	3200
	400 Amp	3400

WORK

3. Size of motor load in HP?	<75	3200
	>75<300	3400

NUMBER OF UNITS

4. How many meters?	1	1
	>1	>1

5. Physical distance from panel to panel to motor load?

<100 FT	1
>100FT	>1